





Just Lock & Load
MISSION ACCOMPLISHED



Coverage may not be sufficient when spraying too far from the surface to be treated. Reduce application speed, or work closer to the surface to avoid uneven and incomplete coverage.



Increase the distance between the nozzle, and application surface if drips or runs occur. Increasing horizontal speed while spraying may also reduce excess buildup.



Apply in a cross-hatch pattern, alternating the direction of strokes. Surfaces should be evenly 'wet' with no drips runs, or gaps.

